

Method for acquisition of acceleration characteristic curve of nanjing remote drive controller


- 1) drive freely to the starting point of acceleration.
- 2) close the key and wait 2 seconds before opening it.
- 3) speed up.
- 4)...

Until you don't want to, 50 seconds is the most.

Pay attention to safety oh, find abnormal to brake in time to give up this time

Acquisition)

- 5) drive back to your computer or phone and leave the electricity on!



Acceleration curve shows that:

Blue: bus current 50A/ grid,

Red: speed line 1000RPM/ grid,

Black: voltage line 5V/ grid, middle line is rated voltage

Time: computer display 5 seconds /1 bar, mobile phone display 5.12 seconds/bar

(after)